

v

```
74 MORE Command Window (id:0) - C:\Users\jacobson\Documents\Time - Upper Right
File Edit Create View Viewing Settings Modes Misc Tools Help

mgd> in p001 rcc
Enter X, Y, Z of vertex: 0 0 0
Enter X, Y, Z of height (H) vector: 0 0 153
Enter radius: 41
p001
mgd> in p002 rcc
Enter X, Y, Z of vertex: 0 0 20
Enter X, Y, Z of height (H) vector: 0 0 133
Enter radius: 36
p002
mgd> in p003 pipe 4
Enter X, Y, Z, inner diameter, outer diameter, and bend radius for first point: 0 30 3
9 10 12 10
Enter X, Y, Z, inner diameter, outer diameter, and bend radius for point 2 : 0 77 39 1
0 12 10
Enter X, Y, Z, inner diameter, outer diameter, and bend radius for point 3 : 0 77 134
10 12 10
Enter X, Y, Z, inner diameter, outer diameter, and bend radius for point 4 : 0 30 134
10 12 10
p003
mgd> z g001 u p001 - p002
Defaulting item number to 1001
Creating region with attrs: region_id=1000, los=100, material_id=1
mgd> z g002 u g001 u p003
Defaulting item number to 1002
Note: g001 is a region
Creating region with attrs: region_id=1001, los=100, material_id=1
mgd>
```